

MODEL	SYSTEM		SUB SYSTEM	TYPE
106 REMODELAGE	DME (ENGINE CONTROL)	PETROL	CDY BOSCH MA3.1 CDZ BOSCH MA3.1 HDY BOSCH MA3.1 HDZ BOSCH MA3.1 HFX BOSCH MA7.4.4 KFW SAGEM S2000 KFX BOSCH MP7.3 KFX MM1AP NFX MM1AP NFX MM48P NFZ BOSCH MP5.2	
		DIESEL	VJU BOSCH VP20 VJX BOSCH VP20	
	TCU(AUTO TRANSMISSION)			
	ABS(ANTI LOCK BRAKE)		ABS TEVES MKIVGI ABS TEVES MK20E	
	SRS(AIR BAG)			
	PROTECT THE VEHICLE		PEUGEOT IMMOBILISER	
HEATING/VENTILATION		WEBASTO ADDITIONAL HEATING		
1007	DME (ENGINE CONTROL)	PETROL	KFV SAGEM 2000 PM2 NFU ME 7.4.4	1.4 1.6
		DIESEL	8HZ SIEMENS SID 804	1.4
	ABS(ANTI LOCK BRAKE)		MK 60 ESP	
	CLIMATE CONTROL			
	SRS(AIR BAG)			
206	DEM (ENGINE CONTROL)	PETROL	7LZ MM5NP HFX MM4.8P RFR MM4.8P RFN MM4.8P HFX MM1AP HFZ MM1AP K6C MM1AP KFW SAGEM S2000 K6D SAGEM S2000 KFX BOSCH MP7.3 KFX MM1AP M6A BPSCH ,E7.4.4 NFU BOSCH ME7.4.4 NFZ BOSCH MP7.2 NFU MM6LP RFK MM6LP RFN MM6LP	

206	DEM(ENGINE CONTROL)	DIESEL	WJY LUCAS DCN2 WJZ LUCAS DCN2 RHY BOSCH EDC15C2 8HX EDC16C3 8HZ BOSCH DEC16C3	
	TCU(AUTO TRANSMISSION)		AL4	
	ABS(ANTI LOCK BRAKE)		ABS TEVES ABS MK70 ESP MK60	
	SRS(AIR BAG)		AIR BAG AND SEAT BELT SIDE AIR BAG(RIGHT SIDE) SIDE AIR BAG (LEFT SIDE)	
	DRIVER INFO/COMMUNICATION		MULTI-FUNCTION DISPLAY ON-BOARD NAVIGATION SYSTEM	
	CONTROL THE OPENINGS		ELECTIC RETRACTABLE ROOF	
	RADIO			
306 REMODELAGE	DME (ENGINE CONTROL)	PETROL	KFW SAGEM S2000 K6D SAGE, S2000 KFX BOSCH MP7.3 KFX MM1AP LFY BOSCH MP7.3 NFT BOSCH M7.4.4 NFV BOSCH M7.4.4 NFZ BOSCH MP5.2 NFZ BOSCH MP7.2 R6E BOSCH MP5.2 RFS MM1AP RFV BOSCH MP5.2	
		DIESEL	DHV BOSCH VP20 DHY BOSCH VP20 RHY BOSCH EDC15C2 WJY LUCAS DCN2 WJZ LUCAG DCN2	
	TCU(AUTO TRANSMISSION)			
	ABS(ANTI LOCK BRAKE)			
	SRS(AIR BAG)		AIR BAG AND SEAT BELT SIDE AIR BAG(RIGHT SIDE) SIDE AIR BAG (LEFT SIDE)	
	PROTECT THE VEHICLE		PEUGEOT IMMOBILISER	A9A DHV DHY DJY KFX MM1AP KFX BOSCH MP7.3 KFX SAGEM SL96 L6A LFY SAGEM SL96 LFY BOSCH MP 7.3 LFZ NFT NFV NFZ BOSCH MP5.2 NFZ BOSCH MP7.2 R6E RFS RFV RHY WJY WJZ

307	DME (ENGINE CONTROL)	PETROL	N6A BOSCH ME7.4.4 NFU BOSCH ME7.4.4 KFW SAGEM S2000 K6D SAGEM S2000 RFN MM48P RFN MM4MP2 KFU MM6LP RFK MM6LP RFN MM6LP
		DIESEL	8HZ BOSCH EDC16C3 9HZ BOSCH EDC16C3 9HY BOSCH EDC16C3 RHS BOSCH EDC15C2 RHY BOSCH EDC15C2 RHZ BOSCH EDC15C2 RHY SIEMENS SID 801 RHR SIEMENS SID 803
	TCU(AUTO LOCK BRAKE)		
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3 ABS BOSCH 8 ESP BOSCH 5.7 ESP BOSCH 8
	SRS(AIR BAG)		
	BSI (BUILT-IN SYSTEM INTERFACE)		BSI DEFAULT SW VERS : 10 -> 18 SW VERS : 20 -> 21 SW VERS : 31 SW INDEX : 0 SW VERS : 32 SW INDEX : 2 SW VERS : 33 SW INDEX : 5 SW VERS : 34 SW INDEX : 0 SW VERS : 34 SW INDEX : 20 SW VERS : 35 SW INDEX : 0 SW VERS : 35 SW INDEX : 20
	DIESEL ADDITIVE FUNCTION ALARM		MARWEL
	DRIVER INFO/COMMUNICATION		DISPLAY /TELEMATIC PARK AID RADIO CD PLAYER INSTRUMENT PANEL
	VISIBILITY/LIGHTING ROLL-OVER ECU		DRIVING SCHOOL
	CONTROL THE OPENINGS		DRIVER DOOR MODULE PASSENGER DOOR MODULE RETRACTABLE ROOF SUN ROOF
	HEATING/VENTILATION		
	CLIMATE CONTROL		SAGEM
	INSTRUMENT		ACC
	ELECTRIC PUMP UNIT		
406	DME (ENGINE CONTROL)	PETROL	LFX MM1AP LFY BOSCH MP5.1.1 LFY BOSCH MP5.2 LFY BOSCH MP7.3 R6E BOSCH MP5.2 RFV BOSCH MP5.1.1 RFV BOSCH MP5.2 RGX BOSCH MP3.2

406	DME (ENGINE CONTROL)	DIESEL	DHX BOSCH VP20 P8C LUCAS EPIC RHZ BOSCH DEC15C2
	TCU(AUTO TRANSMISSION)		4HP20 AL4
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH ABS BOSCH 5.3
	SRS(AIR BAG)		AIR BAG AND SEAT BELT SIDE AIR BAG(RIGHT SIDE) SIDE AIR BAG (LEFT SIDE)
	CLIMATE CONTROL		CLIM_D9
	INSTRUMENT		VDO
	DIESEL ADDITIVE FUNCTION		MARWEL
	PEUGEOT IMMOBILISER		BFZ DHV DHW DHX L6A LFX LFY.BOSCH MP5.2 LFY.BOSCH MP7.3 LFY.SAGEM SL96 P8C R6E RFV RGX RHZ XFZ
406 NOUVELLE	DEM(ENGINE CONTI	PETROL	3FZ MM4MP2 6FZ SAGEM S2000 RLZ SIMENS SIRIUS 91 LFX MM1AP LFY BOSCH MP5.2 LFY BOSCH MP7.3 R6E BOSCH MP5.2 R6F MM4.8P RFR MM4.8P RFN MM4.8P RFV BOSCH MP5.2 XFX BOSCH ME7.4.6
		DIESEL	4HX BOSCH EDC15C2 RHY BOSCH EDC15C2 RHZ BOSCH EDC15C2
	TCU(AUTO TRANSMISSION)		4HP20 AL4
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3 ESP BOSCH 5.3
	SRS(AIR BAG)		AIR BAG AND SEAT BELT SIDE AIR BAG(RIGHT SIDE) SIDE AIR BAG (LEFT SIDE)
	BSI (BUILT-IN SYSTEM INTERFACE)		3FZ 4HX 6FZ BFZ L6A LFX LFY. BOSCH LMP5.2 LFY. BOSCH LMP7.3

406 NOUVELLE	BSI(BUILT-IN SYSTEM INTERFACE)		LFY. SAGEM SL96 R6E R6F RFN RFR RFV RHY RHZ RLZ XFX XFZ SW VERS : 4 SW INDEX : 24 SW VERS : 4 SW INDEX : 27
	DRIVER INFO/COMMUNICATION		MULTI-FUNCTION DISPLAY RADIO CD PLAYER INSTRUMENT PANEL ON-BOARD NAVIGATION SYSTEM
	HEATING/VENTILATION		
406 COUPE	DME	PETROL	RFV BOSCH MP5.2
	TCU(AUTO TRANSMISSION)		4HP20 AL4
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH ABS BOSCH 5.3
	SRS(AIR BAG)		AIR BAG AND SEAT BELT SIDE AIR BAG(RIGHT SIDE) SIDE AIR BAG (LEFT SIDE)
	PEUGEOT IMMOBILISER		R6E RFV XFZ
407	DME (ENGINE CONTROL)	PETROL	RFJ MM 6LP RFN MM 6LP
		DIESEL	RHR SIEMENS SID 803 9HZ BOSCH EDC16C3
607	DME (ENGINE CONTROL)	PETROL	3FZ MM4MP2 RFN MM4MP2 RFN MM48P R6F MM4.8P XFX BOSCH ME7.4.6
		DIESEL	4HX BOSCH EDC15C2 RHS BOSCH EDC15C2 RHZ BOSCH EDC15C2
	TCU(AUTO TRANSMISSION)		4HP20
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3 ESP BOSCH 5.3
	SRS(AIR BAG)		
	BSI (BUILT-IN SYSTEM INTERFACE)		3FZ 4HX R6F RHS RFN XFX RHZ EDC 15C2 SAGEM SW VER : 255
	DIESEL ADDITIVE FUNCTION		MARWEL
	DRIVER INFO/COMMUNICATION		MULTI-FUNCTION DISPLAY PARK AID RADIO

607	DRIVER INFO/COMMUNICATION		CD PLAYER INSTRUMENT PANEL RADIO TELEPHONE HANDS FREE KIT ON-BOARD NAVIGATION SYSTEM
	VISIBILITY/LIGHTING		HEADLAMP HEIGHT CORRECTOR
	CONTROL THE OPENINGS		DRIVER DOOR MODULE PASSENGER DOOR MODULE
	HEATING/VENTILATION		
	CLIMATE CONTROL		CLIM_Z8
	INSTRUMENT		VDO
	STORING OF DRIVING POSITION		
806	DME (ENGINE CONTRL)	PETROL	RFN MM4.9P R6F MM4.8P RFV BOSCH MP7.3 RGX BOSCH MP3.2
		DIESEL	DHX BOSCH VP20 P8C LUCAS EPIC RHW BOSCH DEC15C2 RHZ BOSCH EDC15C2
	TCU(AUTO TRANSMISSION)		AL4
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3
	HEATING/VENTILATION		WEBASTO ADDITIONAL HEATING
807	DME (ENGINE CONTROL)	PETROL	RFN MM48P 3FZ MM4MP2 RFN MM4MP2 3FZ MM6LP RFN MM6LP XFW BOSCH ME746
		DIESEL	RHW BOSCH EDC 15C2 RHM BOSCH EDC 15C2 RHT BOSCH EDC 15C2 4HW BOSCH EDC 15C2
	TCU(AUTO TRANSMISSION)		4HP20 AL4
	ABS(ANTI LOCK BRAKE)		ABS BASCH 5.7 ESP BOSCH 5.7
	SRS(AIR BAG)		
	BSI (BUILT-IN SYSTEM INTERFACE)		BSI DEFAULT SW VERS : 24 SW INDEX : 10 SW VERS : 27 SW INDEX : 14 SW VERS : 30 SW INDEX : 10
	DIESEL ADDITIVE FUNCTION ALARM		MARWEL
	DRIVER INFO/COMMUNICATION		DISPLAY/TELEMATICS RADIO/TELEMATYIC RECEIVE CTRL PARK AID WARNING LIGHTS & ODOMETER ECU INSTRUMENT PANEL CD PLAYER
	VISIBILITY/LIGHTING		RIGHT HEADLAMP BEAM CORRECTOR LEFT HEADLAMP BEAM CORRECTOR
	CONTROL THE OPENINGS		DRIVER DOOR MODULE PASSENGER DOOR MODULE SLIDING SIDE DOOR FRONT SUNROOF REAR SUNROOF MIDDLE SUNROOF

807	HEATING/VENTILATION		WEBASTO ADDITIONAL HEATING CLIMATE CONTRL
	CLIMATE CONTROL		MAGNETI MARELLI
	INSTRUMENT		MAGNETI MARELLI
	STORING OF DRIVING POSITION		
PARTNER	DME (ENGINE CONTRL)	PETROL	HDY BOSCH MA3.1 HDZ BOSCH MA3.1 HFX BOSCH M7.4.4 KFW SAGEM S2000 K6D SAGEM S2000 KFX BOSCH MP7.3 KFX MM1AP LFX MM1AP N6A BOSCH ME7.4.4 NFU BOSCH ME7.4.4
		DIESEL	RHY SIEMENS SID801 RHY BOSCH EDC15C2 WJY LUCAS DCN2 WJZ LUCAS DCN2
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH
	BSI(BUILT-IN SYSTEM INTERFAC		SIEMENS
	INSTRUMENT		MAGNETI MARELLI
	SRS(AIR BAG)		
	EXPERT	DME(ENGINE CONTRL)	PETROL
DIESEL			DHX BOSCH VP20 RHW BOSCH EDC15C2 RHX BOSCH EDC15C2 RHZ BOSCH EDC15C2 WJY LUCAS DCN2
TCU(AUTO TRANSMISSION)		AL4	
ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3	
SRS(AIR BAG)			
BOXER	DME (ENGINE CONTRL)	PETROL	MM4.8P 2L UNLEADED PETORL MM48P 2L ESSENCE PLOMBEE 8140.43S BOSCH EDC 15C7 MM48P 2L DUAL FUEL(LPG)
		DIESEL	2.0L HDI BOSCH EDC15C7 2.2L HDI BOSCH EDC15C7 2.8L HDI BOSCH EDC15C7
	TCU(AUTO TRANSMISSION)		4HP20
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3
	SRS(AIR BAG)		